


## 常用套件组合 / Set general introduction


### HEE系列18回路接插件套件 HEE series 18 Poles of connector




### 配套外壳 / Suit hood/housing

H10B 上壳 H10B hood	螺纹 Thread	型号 Type	图纸 Drawing
----------------------	--------------	------------	---------------

外壳上壳: 侧面进线  
Hood: Side entry




外壳上壳: 顶部进线  
Hood: Top entry





H10B 上壳/底座 H10B hood/housing	螺纹 Thread	型号 Type	图纸 Drawing
---------------------------------	--------------	------------	---------------


外壳上壳: 顶部进线  
Hood: Top entry




外壳底座: 开孔安装  
Bulkhead: mounted



带保护盖  
Without protection covers  
H10B-AD-BO




外壳底座: 表面安装  
Surface mounted: Side entry



## 常用套件组合 / Set general introduction



### HEE系列32回路接插件套件 HEE series 32 Poles of connector



### 配套外壳 / Suit hood/housing

H16B 上壳 H16B hood	螺纹 Thread	型号 Type	图纸 Drawing
----------------------	--------------	------------	---------------



外壳上壳: 侧面进线  
Hood: Side entry



侧面带双扣上壳  
Side entry housing with 2 levers




外壳上壳: 顶部进线  
Hood: Top entry




H16B 上壳/底座 H16B hood/housing	螺纹 Thread	型号 Type	图纸 Drawing
---------------------------------	--------------	------------	---------------


外壳上壳: 顶部进线  
Hood: Top entry




顶部带双扣上壳  
Top entry housing with 2 levers





外壳底座: 开孔安装  
Bulkhead: mounted



外壳底座: 表面安装  
Surface mounted: Side entry




4耳带盖底座  
Bulkhead mounted with 2 bolts



常用套件组合 / Set general introduction


HEE系列46回路接插件套件 HEE series 46 Poles of connector




配套外壳 / Suit hood/housing

H24B 上壳 H24B hood	螺纹 Thread	型号 Type	图纸 Drawing
----------------------	--------------	------------	---------------

外壳上壳: 侧面进线  
Hood: Side entry




外壳上壳: 顶部进线  
Hood: Top entry




H24B 上壳/底座 H24B hood/housing	螺纹 Thread	型号 Type	图纸 Drawing
---------------------------------	--------------	------------	---------------

外壳上壳: 顶部进线  
Hood: Top entry




外壳底座: 开孔安装  
Bulkhead: mounted



外壳底座: 表面安装  
Surface mounted: Side entry




4耳带底座  
Bulkhead mounted with 2 bolts



常用套件组合 / Set general introduction


HEE系列64回路接插件套件 HEE series 64 Poles of connector




配套外壳 / Suit hood/housing

H32B 上壳 H32B hood	螺纹 Thread	型号 Type	图纸 Drawing
----------------------	--------------	------------	---------------

外壳上壳: 侧面进线  
Hood: Side entry




外壳上壳: 顶部进线  
Hood: Top entry




H32B 底座 H32B housing	螺纹 Thread	型号 Type	图纸 Drawing
-------------------------	--------------	------------	---------------

外壳底座: 开孔安装  
Bulkhead: mounted




外壳底座: 开孔安装  
Bulkhead: mounted






常用套件组合 / Set general introduction


HEE系列92回路接插件套件 HEE series 92 Poles of connector



HEE-092-M









HEE-092-F



H48B底座锁扣有普通金属单扣和塑料保护盖  
HEE系列芯件均为冷压针(HEE)压接型, 冷压针需另外订购

配套外壳 / Suit hood/housing

H48B 上壳/底座 H48B hood/housing	螺纹 Thread	型号 Type	图纸 Drawing
外壳上壳: 侧面进线 Hood: Side entry	PG29 PG36 M40	H48B-TS-RO-PG29 H48B-TS-RO-PG36 H48B-TS-RO-M40	
外壳上壳: 顶部进线 Hood: Top entry	PG29 PG36 M40	H48B-TG-RO-PG29 H48B-TG-RO-PG36 H48B-TG-RO-M40	
外壳底座: 开孔安装 Bulkhead: mounted		H48B-AG-LB	
		H48B-AD-LB	
外壳底座: 表面安装 Surface mounted: Side entry	PG29 PG36 M40	H48B-SGR-LB-PG29 H48B-SGR-LB-PG36 H48B-SGR-LB-M40	
	PG29 PG36 M40	H48B-SDR-LB-PG29 H48B-SDR-LB-PG36 H48B-SDR-LB-M40	



HD/HDD INSERT SERIES  
HD/HDD插体系列  
超高密度连接器